

Appendix I

Laser Beam Profiles

a better resolution than 1 in 10. In addition, the better resolution occurs near the region of greatest interest, the damage threshold. A drawback to this measurement method is the large number of sites that must be irradiated. Using this test on small samples remains difficult however, it may be useful on larger samples such as the 2-inch optics.

The third laser damage measurement was discussed by Bass ⁽²⁾ and may possibly be used to determine the probability of damage at levels below the measured damage threshold. This work is based on the premise that even below the "0"-probability of damage level a part will exhibit damage given enough shots. The basis for this assumption is that laser damage is a statistical process. At low fluences the probability of damage may be vanishingly small. However, if a system is expected to accrue many shots, damage may again become statistically important. In this measurement a part is irradiated with one shot in a chosen number of sites and the percentage of sites which fail is recorded. The percentage of sites which fail are plotted on a logarithmic scale and a curve fitted to the points.


In this report all 10 of the laser mirrors were tested using the *DFM* method. Because of the large aperture of the parts, 5 samples measured using the *DFM* method were also measured using the *MDFM* method. This allowed a direct comparison between the results for the given test procedures. As part of this study 4 samples were laser conditioned after the initial *DFM* method. The parts again underwent a *DFM* test to determine the effect of the conditioning. The final sample was measured using *DFM* with the remainder of the part irradiated according to the Bass ⁽²⁾ technique.

3. Test Specifications


3.1 Test Setup

The following section describes the test setup and laser parameters utilized throughout this series of laser damage tests.


The laser source was a Gaussian reflectivity Nd:YAG oscillator. This system provided a Gaussian beam with better than 85% fit to Gaussian in the near field and better than 90% fit to Gaussian in the far field. This laser provided an output of 450 mJ at 1064 nm in a linearly polarized beam. The laser was operated with a PRF of 10 Hz with a 4 ns pulsewidth at the FWHM. The laser was passed through a 1/2 waveplate-thin film polarizer combination to allow for energy adjustment without thermally effecting the laser source. The laser energy was measured using a Scientech astral volumetric absorbing calorimeter capable of measuring 10 Watts of average power. A schematic of the experiment is shown in Figure 1. The laser was focused to a spot diameter of 1.01 mm using a slightly defocused Galilean telescope. This focusing system provides a long Rayleigh range mitigating beam size changes due to the possibility of a slight positioning error of the sample. The spot size was measured with a Spiricon LBA -100A beam analyzer. The beam analyzer provided a Gaussian fit and calculated the $1/e^2$ beam radius.




Horizontal Cursor Profile




Vertical Cursor Profile






Horizontal Cursor Profile



Vertical Cursor Profile



D86e / Knife Edge Diameter Level

Total 88.36% 987772
- Peak 3 227
Peak Location (988.00, 1027.52) μm
Centroid (1016.95, 1029.68) μm
- Diameter 1127.70 μm
X,Y 1090.94, 1080.41 μm

Elliptical Beam

- Orientation -89
Roundness 0.990

-Gauss Fit M,m aligned


Center, Width (11.51, 517.33) μm
Height 224
- Correlation 0.49 0.942


center, width (7.98, 514.45) μm
height 221
- correlation 0.41 0.953

Frame number 1


2/28/97 08:25:22.82
- Calibrated
Cursor (0.00, 0.00)
Aperture Circle
- Center (1007.76, 997.88)
Diam 1580.80 μm
Zoom: Medium
- Pan Window (328, 88)
No Lens
Pixel Scale 9.88 μm

- Spiricon LBA-100A V4.54






Horizontal Cursor Profile



Vertical Cursor Profile



086e / Knife Edge Diameter Level

Total 87.93% 974736
- Peak 3 213
Peak Location (1027.52, 1007.76) μm
Centroid (1012.30, 1008.44) μm
- Diameter 1157.07 μm
X,Y 1146.44, 1121.23 μm

Elliptical Beam

- Orientation 75
Roundness 0.978

-Gauss Fit M,m aligned


Center, Width (-31.14, 527.72) μm
Height 207
- Correlation 0.36 0.951

center, width (17.09, 520.77) μm
height 203
- correlation 0.40 0.949


Frame number 1

- 2/28/97 08:29:32.02
Calibrated
Cursor (988.00, 948.48)
Aperture Circle
- Center (1007.76, 997.88)
Diam 1580.80 μm
Zoom: Medium
Pan Window (328, 88)
To Lens
Pixel Scale 9.88 μm


- Spiricon LBA-100A V4.54



Horizontal Cursor Profile



Vertical Cursor Profile



D86e / Knife Edge Diameter Level

Total 88.17% 980136
- Peak 3 228
Peak Location (1007.76, 1007.76) μm
Centroid (1021.21, 1011.20) μm
- Diameter 1139.32 μm
X,Y 1113.66, 1078.93 μm

Elliptical Beam

- Orientation -70
Roundness 0.969

-Gauss Fit M,m aligned


Center, Width (26.00, 523.78) μm
Height 220
- Correlation 0.63 0.927

center, width (2.30, 499.59) μm
height 217
- correlation 0.54 0.926


Frame number 2

- 2/28/97 08:30:00.88
Calibrated
Cursor (1007.76, 988.00)
Aperture Circle
-Center (1007.76, 997.88)
Diam 1580.80 μm
Zoom: Medium
-Pan Window (328, 88)
No Lens
Pixel Scale 9.88 μm


-Spiricon LBA-100A V4.54



Horizontal Cursor Profile



Vertical Cursor Profile



D86e / Knife Edge Diameter Level

Total 88.36% 987772
- Peak 3 227
Peak Location (988.00, 1027.52) μm
Centroid (1016.95, 1029.68) μm
- Diameter 1127.70 μm
X,Y 1090.94, 1080.41 μm

Elliptical Beam

- Orientation -89
Roundness 0.990

-Gauss Fit M,m aligned


Center, Width (11.51, 517.33) μm
Height 224
- Correlation 0.49 0.942

center, width (7.98, 514.45) μm
height 221
- correlation 0.41 0.953

Frame number 1

2/28/97 08:25:22.82
- Calibrated
Cursor (0.00, 0.00)
Aperture Circle
- Center (1007.76, 997.88)
Diam 1580.80 μm
Zoom: Medium
- Pan Window (328, 88)
No Lens
- Pixel Scale 9.88 μm

- Spiricon LBA-100A V4.54




086e / Knife Edge Diameter Level
 Total 88.44% 985120
 Peak 3 220
 Peak Location (1007.76, 1007.76) μm
 Centroid (1021.16, 1000.10) μm
 Diameter 1141.50 μm
 X,Y 1133.00, 1069.32 μm

Elliptical Beam
 Orientation -76
 Roundness 0.944


Gauss Fit M,m aligned
 Center, Width (14.04, 545.39) μm
 Height 214
 Correlation 0.59 0.927
 center, width (5.11, 499.16) μm
 height 214
 correlation 0.48 0.937

Frame number 1
 2/28/97 08:29:13.37
 Calibrated
 Cursor (1007.76, 968.24)
 Aperture Circle
 Center (1007.76, 997.88)
 Diameter 1580.80 μm
 Zoom: Medium
 Scan Window (328, 88)
 Lens
 Pixel Scale 9.88 μm


Diricon LBA-100A V4.54



Horizontal Cursor Profile



Vertical Cursor Profile



86e / Knife Edge Diameter Level
 Total 88.28% 978596
 Peak 3 218
 Peak Location (968.24, 908.96) μm
 Centroid (995.08, 970.99) μm
 Diameter 1159.00 μm
 X, Y 1144.34, 1118.44 μm

Elliptical Beam
 Orientation -56
 Roundness 0.977

Gauss Fit M, m aligned
 Center, Width (31.79, 541.12) μm
 Height 211
 Correlation 0.43 0.935

center, width (-8.38, 507.91) μm
 height 209
 correlation 0.38 0.941

ame number 1
 2/28/97 08:28:49.31
 alibrated
 rsor (1007.76, 928.72)
 erture Circle
 enter (1007.76, 997.88)
 iam 1580.80 μm
 om: Medium
 an Window (328, 88)
 Lens
 ixel Scale 9.88 μm

piricon LBA-100A V4.54

086e / Knife Edge Diameter Level
Total 88.36% 987772
Peak 3 227
Peak Location (988.00, 1027.52) μm
Centroid (1016.95, 1029.68) μm
Diameter 1127.70 μm
X,Y 1090.94, 1080.41 μm

Elliptical Beam
Orientation -89
Roundness 0.990

Gauss Fit M,m aligned
Center, Width (11.51, 517.33) μm
Height 224
Correlation 0.49 0.942

center, width (7.98, 514.45) μm
height 221
correlation 0.41 0.953

Frame number 1
2/28/97 08:25:22.82
Calibrated
Cursor (1007.76, 1007.76)
Aperture Circle
Center (1007.76, 997.88)
Diameter 1580.80 μm
Zoom: Medium
Pan Window (328, 88)
To Lens
Pixel Scale 9.88 μm

Spiricon LBA-100A V4.54